


TINY Round Installation Manuals

Trimless



Note:
The external driver is remotely located and can be wired to multiple lights in either parallel or series, depending on the specific driver solution.
It's recommended to consult with AMLUMEN experts for further guidance.



- To secure safety, a qualified electrician is required to install/remove the luminaire.
- POWER OFF!!! NOT HOT PLUGGING!!!